

ZCM-12, ZCM-12P/U TIME PROGRAMMER WEEK'S, DOUBLE CHANNEL

INSTRUCTION MANUAL



ZAMEL Sp. z o.o.

ul. Zielona 27, 43-200 Pszczyna, Poland
Tel. +48 (32) 210 46 65, Fax +48 (32) 210 80 04
www.zamelcet.com, e-mail: marketing@zamel.pl

zameL

DESCRIPTION

Digital control time switches ZCM-12 are used to realise the time functions in automation and control systems. Weekly programmers realise output relay control operations according to program adjustments (day, time). All systems have some additional features, e.g., a random function, which can be used to simulate presence, a control input function, which is used to change the operating mode of a system by means of an external push-button. An additional advantage of the ZCM-12P/U programmer is the ability to copy the programs adjusted in the time switch into an external memory stick, so they can be easily copied to other programmers. The design of the casing allows the system to be mounted on a TH-35 rail and eventually to seal device. The design of the system provides battery back-up system for all adjustments in the case of no voltage supply.

In order to protect the battery during storage, the ZCM-12 series programmers have a default setting, the so-called storage mode in which the battery power consumption is limited to a minimum.

FEATURES

- Week's cycle control in dependence of the current hour,
- double-module casing with a protection flap,
- random op mode, additional IN control inputs,
- double-channel version,
- many programs,
- LCD display illumination,
- mounted on TH 35 rail,
- a possibility to copy and read programs from the external memory.




The device is designed for single-phase installation and must be installed in accordance with standards valid in a particular country. The device should be connected according to the details included in this operating manual. Installation, connection and control should be carried out by a qualified electrician staff, who act in accordance with the service manual and the device functions. Disassembling of the device is equal with a loss of guarantee and can cause electric shock. Before installation make sure the connection cables are not under voltage. The cruciform head screwdriver 3,5 mm should be used to instal the device. Improper transport, storage, and use of the device influence its wrong functioning. It is not advisable to instal the device in the following cases: if any device part is missing or the device is damaged or deformed. In case of improper functioning of the device contact the producer.

TECHNICAL DATA


ZCM-12, ZCM-12P/U

Power supply terminals:	A1, A2
Input rated voltage:	ZCM-12: 230 V AC (-15 ÷ +10 %) ZCM-12P/U: 24 ÷ 250 V AC, 30 ÷ 300 V DC
Nominal frequency:	50 / 60 Hz
Rated power consumption:	2,1 W / 4 VA
Number of channels:	2
Program quantity:	400 (100 par On/Off na kanal)
Program:	daily, week's
Operating modes:	manual, automatic, random, impulse
Change of season summer/ winter:	automatic, manual
Colour of LCD panel lighting:	amber
Input:	2
Accuracy of time measurement:	max ±1 s / 24 h at temp. 25 °C
Time of clock maintenance:	3 years
Time of programme maintenance:	10 years
Clamps of release system:	IN1, IN1, IN2, IN2
Receiver input (supply) terminals:	11, 12, 14, 21, 22, 24
Output relay parameters:	2 NO/NC-16 A/250 V AC1 4000 VA
Number of terminal clamps:	12
Section of connecting cables:	0,2 ÷ 2,50 mm ²
Ambient temperature range:	-20 ÷ +60 °C
Operating position:	freely
Mounting:	rail TH 35 (EN 60715)
Protection degree:	IP20 (EN 60529)
Protection level:	II
Oversvoltage category:	II
Pollution degree:	2
Dimensions:	double-modular (35 mm) 90 x 35 x 66 mm
Weight:	0,14 kg
Reference standards:	EN 60730-1; EN 60730-2-7 EN 61000-4-2,3,4,5,6,11

APPEARANCE*



DESCRIPTION



Description of elements and messages displayed

Mo Tu We Th Fr Sa Su	dATE - current date setting
On OFF - relay status	rAnd - random mode setting
○ - automatic mode	InPut - external input setting
□ - manual mode	PULSE - impulse mode setting
△ - impulse mode	PEn - external memory operation*
► - external input	SAVE - external memory record*
* - winter time	rERd - external memory reading*
★ - summer time	busy - external memory busy*
DAY - day, YEAR - year	Err - reading / record error*
Prog - program setting	
timE - current time setting	
and summer/winter time shift	

Button description

- • in the main window - enter into the automatic mode or change the relay status if the time switch is in the automatic mode,
- in the main window (3 sec.) - random mode enter / exit,
- in the random mode - manual change of an active / inactive randomness,
- in other windows - exit to the previous level without data record,
- • in the main window - enter into the manual mode or change the relay status if the time switch is in the manual mode,
- in the random mode - relay status change and randomness switch off,
- in other windows - exit to the previous level without data record;
- OK • in the main window - enter the main menu,
- in other windows - enter the sub menu or confirm the adjusted value;
- ◀ ▶ • switching the windows / menu options or increasing / decreasing the adjusted value;

STORAGE MODE


ZCM series programmers have a default setting, the so called storage mode in order to protect the battery during storage.

In case of battery backup operation the storage mode is switched off during the first use of the programmer. It is done by means of a short pressing of the □ push-button and subsequent date and time adjustment.


In case of a nominal power supply the storage mode is switched off during the first use of the programmer by means of date and time adjustment.

Adjusting the programmer into the storage mode is realised by means of a reset - in order to carry it out press at the same time the □ and ○ push-buttons in the main window.

MAIN MENU




DATE SETTING



- ① dATE ** - Current date setting; entry after pressing OK;
- ② YEAR - choose adequate year with cursors ▲ ▼ confirm with OK, range of years: 2000÷2099;
- ③ MONTH - choose month with cursors ▲ ▼ confirm with OK;
- ④ DAY - choose day with cursors ▲ ▼ confirm with OK; the system has a protection against introducing incorrect parameter of a day for a given month (it takes into account leap years and it automatically calculates the day of the week on the basis of an arranged date);
- ⑤ Confirmation causes movement to a date setting window and set-up of current summer/ winter time - if the option Auto is arranged.

It is possible to exit every submenu window in any moment without saving settings by pressing the button ○ or □.


TIME SETTING



- ① $t_{\text{m}} E^{\circ}$ - setting the current clock time; entry after pressing OK;
- ② HOUR - choose adequate hour with cursor $\blacktriangleleft \blacktriangleright$ which you can set in 1-24 H or 1-12 P (AM) and 1-12 P (PM) format; confirm with OK;
- ③ MINUTES - choose adequate parameter of minutes with cursors $\blacktriangleleft \blacktriangleright$ confirm with OK;
- ④ Confirmation of the parameter of minutes causes simultaneous nullification of the parameter of seconds and movement to the window of time setting.

It is possible to exit every submenu window in any moment without saving settings by pressing the button \odot or \ominus .

WINTER / SUMMER TIME SETTING





- ① $t_{\text{m}} E^*$ - winter/summer time toggle mode selection: Auto - automatic time changing on the last March Sunday, at 2:00 into summer time and on the last October Sunday, at 3:00 into winter time, USER - winter/summer timer toggle manual, by user; option entering after pressing OK;
- ② ③ MODE SETTING - with $\blacktriangleleft \blacktriangleright$ select Auto or USER acknowledge with OK; after selecting Auto , winter/summer time will be toggled automatically; after selecting

USER mode you will enter the next window;

- ④ With $\blacktriangleleft \blacktriangleright$ select winter/summer, where * is winter time, * - summer time; if the time icon is changed, the timer will correct the current time appropriately; acknowledge by pressing OK;
- ⑤ After time mode selecting winter/summer time change window will be open.

OPERATING MODE CHANGE (AUTOMATIC, MANUAL, RANDOM)



- ① ② Before the op mode changing it is necessary, in the main window, to select with the cursors $\blacktriangleleft \blacktriangleright$ channel ch-1 or ch-2 .

- ③ MANUAL OP MODE TOGGLE - if the main window is open and the timer is in the automatic mode \odot pressing the key \ominus will force the unit to toggle into the manual mode and the relay state changeover;

- ④ ⑤ Successive \ominus key pressing will force the relay state changeover without the op mode changing;


- ⑥ AUTOMATIC MODE TOGGLE - if the main window is open and the timer is in the manual mode \ominus pressing the key \odot will force the unit to toggle into the automatic mode and the relay state changeover;

- ⑦ ⑧ Successive \odot key pressing will force the relay state changeover without the op mode changing;

- ⑨ RANDOM MODE TOGGLE - in order to enter the random mode it is necessary to press and hold \odot key for 3 SECS;

- ⑩ ⑪ Pressing the key \ominus forces the relay state changeover; in order to exit the random mode it is necessary to press the key \odot .

PROGRAM VIEWING




- ① PROGRAM VIEWING - viewing settings for the switching programs (On / OFF) i.e. hours, minutes and week's days; enter viewing by pressing OK;
- ② With $\blacktriangleleft \blacktriangleright$ cursors select ch-1 or ch-2 ;
- ③ ④ In order to scroll programs press successively the cursors $\blacktriangleleft \blacktriangleright$; cursor \blacktriangleright increases program number; cursor \blacktriangleleft decreases program number;
- ⑤ The programs are numbered in the form of (On / OFF), pairs, where each program

may be treated independently; there are 400 programs (100 On / OFF pairs per channel).


It is possible to exit every submenu window in any moment without saving settings by pressing the button \odot or \ominus .

PROGRAM SETTING



Kombinacje podziału tygodnia

1	Mo
2	Tu
3	We
4	Th
5	Fr
6	Sa
7	Su
8	Mo Tu We Th Fr Sa Su
9	Mo Tu We Th Fr
10	Sa Su
11	Mo Tu We Th Fr Sa
12	Mo We Fr
13	Tu Th Sa
14	Mo Tu We
15	Th Fr Sa Su
16	Mo We Fr Su



① **Pro6** - defining ON-times and OFF-times for the given week's days, for the given programs running in the automatic mode; enter edition by pressing OK; the programs are numbered as (ON / OFF) pair (On / OFF). Maximum number of On / OFF programs is 100 pairs per channel;

② With **↔** cursors select **ch-1** or **ch-2**;

③ With **↔** cursors select the program (e.g. **Pr001 On**) for its parameters editing and enter edition by pressing OK;

④ HOUR - with **↔** cursors select an hour and acknowledge by pressing OK;


⑤ MINUTE - with **↔** cursors select minutes and acknowledge by pressing OK;

⑥ WEEK'S DAY - with **↔** cursors select the week's day when the given program is to be active (there are 16 week division combinations available), acknowledge selection by pressing OK - the program will be saved;

⑦ The next saved program will be displayed (e.g. **Pr001 OFF**) - press OK to enter edition, in order to select the other program use the cursors **↔**, in order to exit the mode press **⊕** or **⊖**;

⑧ The last available program is **Pr100 OFF**.

PROGRAM CANCEL / RESTORE



① PROGRAM CANCEL / RESTORE - the option is used during program setting and viewing for program cancelling (inactivation) and restoring; enter by pressing OK;


② With **↔** cursors select **ch-1** or **ch-2**;

③ With **↔** cursors select the program to be cancelled / restored;

④ Press and hold OK for 3 seconds – if the program is active, it will be canceled (inactivated) and will not be checked during the timer operating in the automatic mode (however it will be saved in the storage and it will be possible to restore the program); horizontal lines will be displayed;

⑤ If the program is cancelled, it will be restored by pressing OK and its edition will be possible ⑥, pressing and holding OK for 3 seconds will cause the program restoring without time edition possibility ⑦.

EXTERNAL INPUT SETTING



① **Input ▶** - setting the unit mode after the IN external input triggering; the module remains in the state until the triggering IN signal decays; enter edition by pressing OK;

② With **↔** cursors select **ch-1** or **ch-2**; After the channel selection with **↔** cursors select an appropriate external input mode, where:

③ **OFF** - external input function is OFF;

④ **On** - manual mode with the continuous relay OFF-state;

⑤ **On** - manual mode with the continuous relay ON-state;


⑥ **On** - automatic mode, the relay switching ON / OFF according to the set programs;

⑦ **Random** mode according to settings from the menu RANDOM MODE SETTING;

⑧ Acknowledge the given mode selection by pressing OK; after acknowledgement the external input setting window will be open.


It is possible to exit every submenu window in any moment without saving settings by pressing the button **⊕** or **⊖**.

IMPULSE PROGRAM SETTING



- ① PULSE ▲ - the impulse generating mode and impulse duration time setting; the impulse mode current state is shown in the display (On - ON, OFF - OFF); enter edition by pressing OK;
- ② With ▲ cursors select ch-1 or ch-2;
- ③ ④ With the cursors ▲ select one of the following options On - ON or OFF - OFF for the impulse mode; acknowledge selection by pressing OK; in case of the OFF state selecting the impulse mode main window will be open;
- ⑤ After selecting On option with ▲ cursors select impulse duration time in seconds; acknowledge selection by pressing OK;
- ⑥ After the selection acknowledgement the impulse mode setting window is open. In the impulse mode there are only ON On programs.

RANDOM MODE SETTING




① rAnd - setting maximum ON and OFF time for the relay in the random mode which is the same for both channels, but switched ON separately; enter the mode by pressing OK; with the cursors ▲ select demanded window, where:

- ② t On - the relay maximum ON-time setting in minutes - the time will be randomized for the time range between 1 minute and t On minutes;
- ③ t OFF - the relay maximum OFF-time setting in minutes - the time will be randomized for the time range between 1 minute and t OFF minutes;


Window ②: press OK to enter; ④ with ▲ cursors set maximum ON-time (in minutes), acknowledge by pressing OK; you will enter window ③.

Window ③: press OK to enter; ⑤ with ▲ cursors set maximum OFF-time (in minutes), acknowledge by pressing OK; you will enter window ④.

It is possible to exit every submenu window in any moment without saving settings by pressing the button ⌂ or ⌂.



EXTERNAL MEMORY OPERATION*




External memory allows for an easy record / reading of the adjusted programs into the external memory, so they can be easily copied to other programmers. It is very convenient in case if we want to program more ZCM programmers or archive the adjusted programs.

- ① PEn - sub menu to the external memory operation
- ② SAVE - programs recording
- ③ rERd - programs reading from the external memory and storage in the programmer's memory
- ④ busy - the state of memory „busy” during a record / reading
- ⑤ Err - record /reading error
- ⑥ done - correct record / reading


MOUNTING

1. Disconnect power supply by the phase fuse, the circuit-breaker or the switch-disconnector combined to the proper circuit.
2. Check if there is no voltage on connection cables by means of a special measure equipment.
3. Install the ZCM-12 on the TH 35 DIN rail in the switchboard.
4. Connect the cables with the terminals in accordance with the installing diagram.
5. Switch on the power supply from the mains.

INNER DIAGRAM



DIMENSIONS




PRODUCT FAMILY

ZCM-12 Programmer belongs to ZCM family of products.

ZCM-xx/U

Power supply:	ZCM-xx - 230 V AC
	ZCM-xx/U - 24 ÷ 250 VAC 30 ÷ 300 V DC
Programmer type:	11 - week (1 channel)
	12 - week (2 channel)
	22 - weekly - year
	31 - astronomical
Device type	

CONNECTION*



RELAY CAPACITY



ADVANTAGES



Intelligent calendar - the programmer is fitted with a built-in calendar which fits leap years automatically, disables entering incorrect dates, calculates a week's day on the basis of the current date and fits the summer / winter time change.


General purpose external input - the programmer is fitted with an external input that enables the operating mode change without operating a switchboard, e.g. by means of a remote push button.

Programmable random mode - it is possible to set beginning and ending time, and the day of the random mode activity. Additionally, it is possible to program maximum ON and OFF times in dependence of user's needs.

Additional impulse mode - it is possible to switch the timer into the impulse mode which gives control units new capabilities.

Cooperation with the external memory* - the user has a possibility of a quick record / reading of the adjusted programs into the external memory in order to copy them in other programmers quickly.

MAIN RESET



- ① In order to cancel the clock system (time, date, activity of given functions etc.) you should hold buttons (OK and ⌂) simultaneously in the main menu for 3 sec;
- ② All the display fields will light up;
- ③ After a while, the clock will automatically set date and time.

Attention: In order to restore factory settings, you should additionally hold button OK

WARRANTY CARD

There is 24 months guarantee on the product

1. ZAMEL provides a two-year warranty for its products.
2. The ZAMEL warranty does not cover:
 - a) mechanical defects resulting from transport, loading / unloading or other circumstances;
 - b) defects resulting from incorrect installation or operation of ZAMEL products;
 - c) defects resulting from any changes made by CUSTOMERS or third parties, to products sold or equipment necessary for the correct operation of products sold;
 - d) defects resulting from force majeure or other aleatory events for which ZAMEL is not liable;
 - e) power supply (batteries) to be equipped with a device in the moment of sale (if they appear);
3. All complaints in relation to the warranty must be provided by the CUSTOMER in writing to the retailer after discovering a defect.
4. ZAMEL will review complaints in accordance with existing regulations.
5. The way a complaint is settled, e.g. replacement of the product, repair or refund, is left to the discretion of ZAMEL.
6. Guarantee does not exclude, does not limit, nor does it suspend the rights of the PURCHASER resulting from the discrepancy between the goods and the contract.

Salesman stamp and signature, date of sale